

IP3552\_665\_QG\_Eng\_GB\_06\_110419.indd 1

# Getting started.....

Removing and installing the back cover



#### Removing and installing the battery



Inserting and removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

You can create a note in text or voice format by accessing "Notes" from the main menu.

#### 15.5 Calculator

Enter a number, select the type of operation to be performed. and enter the second number, then press "=" to display the

#### 15.6 File manager

You will have access to all audio and visual files stored in phone or memory card in File manager. You can access a number of items with this option: My audios, My images, My videos, My creations, Other files, Phone, Memory card and Memory status.

Inserting the memory card



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and slide it in the opposite direction to lock it.

#### 15.7 World clock

The World clock shows current local time and the time zone in

#### Charging the battery



Connect the battery charger to your phone and mains socket respectively

- The charging may take about 20 minutes to start if the battery is flat
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ( IIII ).
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Bluetooth when not in use; reduce the backlight time, etc.



#### 2.2 Power on your phone

Hold down the • J key until the phone powers on.

#### 2.3 Power off your phone

Hold down the and key from the main screen.

# Calls .....

### 3.1 Making a call

Dial the desired number then press the  $\bigcup$  key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the 🔩 key.

#### Making an emergency call

If your phone is covered by the network, dial emergency number and press the L key to make an emergency call. This works even without a SIM card and without typing the PIN code.

#### 3.2 Calling your voicemail (1)

To access your voicemail, hold down the wkey

#### 3.3 Receiving a call

When you receive an incoming call, press the L key to talk and then hang up using the 2 key.

#### 3.4 Available functions during the call

During a call, you can use your directory, your calendar, short messages, etc. without losing your correspondent.

Contact your network operator to check service availability.

## 15.8 Converter

Unit converter and Currency converter.

### 15.9 Stopwatch

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement



Your Alcatel phone may include <sup>(I)</sup> some Java<sup>™</sup> applications and games. You can also download new applications and games to your phone

#### **16.1** Java applications

Select "Java applications" to launch applications.

#### 16.2 Java settings

This menu allows you to manage Java settings, in which you may set Audio, Backlight, Vibration and Heap size.

#### 16.3 Java network

This menu allows you to select the network for Java.

#### 16.4 Trusted certificates

View detailed information of the trusted certificates supported by your phone.

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2011 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice

8

# **7** Applications..... **8**

#### 

Access Wap options: Homepage, Bookmarks, Recent pages, Offline pages, Go to URL, Service inbox, Settings

#### 17.2 Bluetooth<sup>™</sup>

Access this feature by pressing () to enter the main menu, To write messages, there are two writing methods: then selecting "Applications\Bluetooth".

#### 17.3 Local games

Your Alcatel phone may include some games.

### 17.4 News

It is a huge time saver providing news updates from a website in a simple form. Once subscribed to a channel, it gives you the ability to track and manage all your favourite RSS content on your mobile phone at anytime, anywhere!

#### 175 Weather

Your phone is equipped with a weather function for consulting up to 3-day forecasts of favourite cities

#### 17.6 Services

Contact your network operator to check service availability.

Internet address: www.alcatelonetouch.com

go to our Internet site.

any questions you may have.

www.alcatelonetouch.com

€€1588

alcatelonetouch.com

Disclaimer

services

Protection against theft

it, even with a different SIM card.

networks with 900 and 1800 MHz bands.

Hot Line Number: see "TCT Mobile Services" leaflet or

Questions) section. You can also contact us by e-mail to ask

An electronic version of this user guide is available in English

and other languages according to availability on our server:

Your telephone is a transceiver that operates on GSM

This equipment is in compliance with the essential requirements

and other relevant provisions of Directive 1999/5/EC. The

entire copy of the Declaration of Conformity for your

telephone can be obtained through our website: www.

Your telephone is identified by an IMEI (phone serial number)

shown on the packaging label and in the product's memory.

We recommend that you note the number the first time you

use your telephone by entering \* # 0 6 # and keep it in a safe

place. It may be requested by the police or your operator if

your telephone is stolen. This number allows your mobile

telephone to be blocked preventing a third person from using

There may be certain differences between the user manual

description and the phone's operation, depending on the

software release of your telephone or specific operator

TCT Mobile shall not be held legally responsible for such

differences, if any, nor for their potential consequences, which

Contact your network operator to check service availability. 25

responsibility shall be borne by the operator exclusively.

IP3552\_665\_QG\_Eng\_GB\_06\_110419.indd 2

# Profiles .....

With this menu, you may personalise ringtones for different events and environments

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a
- Predictive with the eZi mode: this mode speeds up the
- + key in edit mode
- Short keypress: access the language list

General information ...... Telephone warranty ......

original invoice.

any other costs.

On our Internet site, you will find our FAQ (Frequently Asked purchase as shown on your original invoice.

manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein. TRAFFIC SAFETY-

# Latin input mode...

- writing of your text.

Your phone is warranted against any defect or malfunctioning

which may occur in conditions of normal use during the

warranty period of twelve (12) months (1) from the date of

Batteries (2) and accessories sold with your phone are also

warranted against any defect which may occur during the first

six (6) months <sup>(1)</sup> from the date of purchase as shown on your

In case of any defect of your phone which prevents you from

normal use thereof, you must immediately inform your vendor

If the defect is confirmed, your phone or part thereof will be

either replaced or repaired, as appropriate. Repaired Phone and

accessories are entitled to a one () month warranty for the same

defect. Repair or replacement may be carried out using

This warranty covers the cost of parts and labor but excludes

reconditioned components offering equivalent functionality.

The warranty period may vary depending on your country.

and for approximately 200 more recharges.

The life of a rechargeable mobile phone battery in terms of conversatio

time standby time, and total service life, will depend on the conditions of

use and network configuration. Batteries being considered expendable

supplies, the specifications state that you should obtain optimal

performance for your phone during the first six months after purchase

and present your phone with your proof of purchase.

- Long keypress: enter zero
- - You are advised to switch off the telephone from time to time to optimise its performance.

18

Switch the phone off before boarding an aircraft.

or airbags. To ensure that there is no problem

vehicle is not parked

deployment area

CONDITIONS OF USE-

areas

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use. mobile telephones can interfere with other electrical or electronic devices. or equipment using radio frequency

Safety and use.....

We recommend that you read this chapter carefully before using your phone. The

Given that studies show that using a mobile phone while driving a vehicle

constitutes a real risk even when the hands-free kit is used (car kit

headset...), drivers are requested to refrain from using their mobile when the

When driving do not use your phone and headphone to listen to music or

to the radio. Using a headphone can be dangerous and forbidden in some

When switched on your phone emits electromagnetic waves that can

interfere with the vehicle's electronic systems such as ABS anti-lock brakes.

do not place your phone on top of the dashboard or within an airbag

check with your car dealer or the car manufacturer to make sure that the

dashboard is adequately shielded from mobile phone RF energy.

- Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere. When the phone is switched on, it should be kept at least 15 cm from any
- medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device if any To avoid hearing impairment, pick up the call before holding your phone to
- your ear. Also move the handset away from your ear while using the "handsfree" mode because the amplified volume might cause hearing damage. Do not let children use the phone and/or play with the telephone and
- accessories without supervision. When replacing the cover please note that your phone may contain
- substances that could create an allergic reaction.
- This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):
- Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your phone is used,
- 2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited,
- 8) Modification or repair performed by individuals not authorised by TCT Mobile Limited or its affiliates or your vendor,
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation.
- Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.
- There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.
- In no event shall TCT Mobile Limited or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.
- Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you

#### Always handle your phone with care and keep it in a clean and dust-free place Do not allow your phone to be exposed to adverse weather or environmental anditions (moisture humidity rain infiltration of liquids dust sea air etc) The manufacturer's recommended operating temperature range is -10°C to

- Over 55°C the legibility of the phone's display may be impaired, though this is remporary and not serious.
- Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.
- Do not open, dismantle or attempt to repair your mobile phone yoursel Do not drop, throw or bend your mobile phone
- Do not paint it. Use only batteries, battery chargers, and accessories which are recommended
- by TCT Mobile Limited and its affiliates and are compatible with your phone model TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries
- Remember to make back-up copies or keep a written record of all important information stored in your phone
- Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.
- Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:
- Do not play or use a flashing-lights feature if you are tired or need sleep. Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands wrists or arms during or after playing stop the game and see a doctor

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.

## Troubleshooting.....

- Before contacting the aftersales department, you are advised to follow the instructions below
- You are advised to switch off the telephone from time to time to optimise its performance.
- You are advised to fully charge ( find ) the battery for optimal operation.
- Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.
- and carry out the following checks:
- My mobile phone will not switch on
- Press \_\_\_\_ until the screen comes or Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then turn your telephone back on
- My phone has not responded for several minutes
- Press the 🔄 key Remove the battery and re-insert it, then switch the phone
- My screen is difficult to read

back on

27

- Clean your screen
- Use your mobile phone in accordance with the recommended conditions of use

#### My mobile phone turns off by itself

Check that your keypad is locked when you are not using your mobile phone Check the battery charge level

## My mobile phone has a low level of autonomy

- Make sure you respected the complete charge timing (minimum 3 hours)
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication

### • PRIVACY

ease note that you must respect the laws and regulations in force in you on or other jurisdiction(s) where you will use your mobile phone arding taking photographs and recording sounds with your mobile ne. Pursuant to such laws and regulations, it may be strictly forbidd e photographs and/or to record the voices of other people or any their personal attributes and duplicate or distribute them as this may h nsidered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to recor vate or confidential conversations or take a photograph of another person the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the

### BATTERY

20

Before removing the battery from your phone, please make sure that the phone is switched off Observe the following precautions for battery use

- Do not attempt to open the battery (due to the risk of toxic fumes and burns). o not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C. Batteries must be disposed of in accordance with locally applicable

mental regulations. Only use the battery for the purpose for which it vas designed. Never use damaged batteries or those not recommended b TCT Mobile Limited and/or its affiliates.

- This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life
- Municipal waste disposal centres with specific bins for these model are: items of equipment
- Collection bins at points of sale They will then be recycled, preventing substances being disposed of in the ment. so that their components can be reused Head SA In European Union countries:
- These collection points are accessible free of charge
- All products with this sign must be brought to these collection points In non European Union jurisdictions

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled

CALITION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE, DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

My mobile phone will not charge properly

29

- Make sure that your battery is not completely discharged; If the battery is flat, it may take around 20 minutes to display the battery charger indicator on the screen
- Make sure charging is carried out under normal conditions (0°C - +40°C) Make sure your battery is inserted. It must be inserted
- before plugging in the charger
- Make sure you are using an Alcatel battery and charger in the box • When abroad, check that the electrical current is
- compatible

Try connecting at a later time if the network is overloaded

Verify with your operator that your SIM card is 3V or 1.8V

Make sure the chip on your SIM card is not damaged or

Make sure you have dialled a valid number and press the

Make sure your mobile phone is connected to a network,

Check your subscription status with your operator (credit,

For international calls, check the country and area codes.

and that the network is not overloaded or unavailable

Make sure you have not barred outgoing calls

#### My mobile phone will not connect to a network Try connecting in another location Verify the network coverage with your operator Check with your operator that your SIM card is valid.

Try selecting the available network(s) manually

Make sure the SIM card has been correctly inserted

compatible; the old 5V SIM cards cannot be used

Unable to make outgoing calls

SIM card error

scratched

key

SIM card valid, etc.)

#### • CHARGERS

to 40°C

Mains powered chargers will operate within the temperature range of 0°C

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one iurisdiction may not work in another iurisdiction. They should be used for this purpose only

#### RADIO WAVES

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device

Maximum SAR for this model and conditions under which it was recorded.		
Head SAR	GSM900+Bluetooth	0.93 W/kg
Body-worn SAR	GSM900+Bluetooth	0.9 W/kg

During use, the actual SAR values for this device are usually well below the • LICENCES values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 1.5 cm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away fron

The World Health Organization has stated that present scientific informatio does not indicate the need for any special precautions for the use of mobile devices. They recommend that if you are interested in further reducing your exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body.

For more information you can go to yoww alcatelonetouch co Additional information about electromagnetic fields and public health are

available on the following site: http://www.who.int/peh-emf. Your telephone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in position other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 1.5 cm away from the body

Micro



eZiText<sup>®</sup>

Java

facebook

**z** corporation

is a registered trademark of Obigo AB. microSD Logo is a trademark.

The Bluetooth word mark and logos are owned by the Bluetooth SIG. Inc. and any use of such marks by TCT Mobile Limited and its affiliates is under license. Other trademarks and trad names are those of their respective owners.

#### one touch 665 Bluetooth QD ID B016876

eZiText<sup>™</sup> and Zi<sup>™</sup> are trademarks of Zi Corporation and/or its Affiliate

lava<sup>™</sup> and all lava<sup>™</sup> based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other

Opera Mini<sup>™</sup> is a registered trademark of Opera Mini.

Facebook and the f Logo are trademarks of Facebook, Inc., and are used under license

#### Unable to receive incoming calls

 Make sure your mobile phone is switched on and connected to a network (check for overloaded or unavailable network)

· Check your subscription status with your operator (credit, SIM card valid, etc.)

Make sure you have not forwarded incoming calls

Make sure that you have not harred certain calls The caller's name does not appear when a call is

received

Check that you have subscribed to this service with your operator

Your caller has concealed his/her number

The sound quality of the calls is not optimal

You can adjust the volume during a call by means of the

#### Check the network strength and

I am unable to use the features described in the manual Check with your operator to make sure that your subscription includes this service

 Make sure this feature does not require an Alcatel accessory

#### When I select a number from my directory, the number is not dialled

 Make sure that you have correctly recorded the number in your file

Make sure that you have selected the country prefix when calling a foreign country

#### I am unable to add contact in my directory

 Make sure that your SIM card directory is not full: delete some files or save the files in the product directory (i.e. your professional or personal directories)

#### My callers are unable to leave messages on my voicemail

Contact your network operator to check service availability

I cannot access my voicemail

- Make sure your operator's voicemail number is correctly entered in "My number"
- Try later if the network is busy
- I am unable to send and receive MMS
- Check your phone memory available as it might be full
- Contact your network operator to check service availability and check MMS parameters
- Verify the server centre number or your MMS profile with your operator
- The server centre may be saturated; try again later
- The icon is displayed on my standby screen
- You have saved too many short messages on your SIM card: delete some of them or archive them in the product memory

#### "No service" is displayed

- You are outside of the network coverage area
- I have already entered 3 incorrect PIN codes
- Contact your network operator to obtain the PUK code (Personal Unblocking Key
- I am unable to download new files
- Check for free space
- Delete some files
- Check your subscription status with your operator
- My mobile phone is frozen, can't power on
- Make sure your battery is not completely used up or damaged
- Remove your battery, remove your SIM card then reinstall
- them to power on again, if still does not work
- Hold down # key and press Power on/off key for a while to reset the phone



ALL User phone data: contacts, photos, messages and files, downloaded applications like Java games will be lost permanently

#### How to make your battery last longer

- · Make sure you followed the complete charge time (minimum 3 hours).
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request.
- Extend email auto-check interval as long as possible.
- Update news, weather info, upon demand manually or set
- its auto-check interval longer Exit Java background-running applications if they are not being used for a long time.
- Deactivate Bluetooth when not in use.

#### One Touch Upgrade

Using One Touch Upgrade tool you can update your phone's software from your PC.

Download One Touch Upgrade from ALCATEL website (www.alcatelonetouch.com) and install it on your PC.Launch the tool and update your phone by following the step by step instructions (refer to the User Guide provided together with the tool)

Your phone's software will now have the latest software.



All personal information will be permanently lost following the update process. We recommend you backup your personal data using PC Suite before upgrading.

32

