

### 1. Packing List

1. Prestigio MultiPhone

AC Adapter

3. Earphone 6. Warranty Card

4. USB Cable 5. Quick Start Guide 7. Legal and Safety Notices 8. Battery

# 2. Device Overview

El Device Overview		
0	Earphone Jack	Earphone connection.
2	Menu	Display menu options
3	Home	Back to the Home screen
4	Back	Back up to the previous page
5	USB port	Micro USB cable connection
6	Vol +\ Vol - Button	Adjust the volume level
7	Camera	Take photos
8	Speaker	Listen to phone calls or music
9	Power	Turn on/off the device;
		Suspend/Activate the device



# 3. Uninstalling the back cover and battery

 Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.

Prestigio PAP3500





• Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.

**Notice**: Your device must be powered off before exchanging or uninstalling the battery.

4. Installing the SIM cards and Micro SD card



PAP3500



#### a. Insert SIM cards

- The slot at the bottom is card 1 slot and for 3G WCDMA card (compatible with 2G card), another is card 2 slot and for GSM card
- Please make sure the gold contact area on the card is facing downwards.

#### b. Insert Micro SD card

- Insert Micro SD card into the Micro SD card slot with the metallic pins facing downwards. Push the card until it locks into place.
- To remove the micro SD card, pull the card out of the slot.

## 5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3~4 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the time of full charging.
  - Notice: If you don't use your phone for a long time, it will gradually discharge. Please charge it first before your next use or charge the phone every 3 months even you don't use it.

## 6. Power on/Sleep Mode/Power off

- Press and hold the Power Button for a few seconds. It will automatically enter the Home screen after start-up screen.
- Press the **Power Button** once to enter sleep mode and press it again to awake the device.



Press and hold the **Power Button**, and then tap on **Power off** to power off the device. Technical Specifications

Oualcomm MSM7225A-AB at 1 GHz Processor

256Mb RAM + 512Mb ROM, Micro SD slot supports up to 32GB Memory

os Andriod 2.3.5 (Gingerbread)

Display 3.45-inch TN LCD, Capacitive touch (2 Dots)

Resolution 320x480 pixels

Net Mode WCDMA + GSM (UMTS:2100MHz; GSM:900/1800MHz)

Interfaces USB 2.0, Micro SD, USB Host Communications WiFi (802.11b/g/n), 3G

**Battery** 1400 mAh Lithium-ion Polymer Battery

Dimensions 116x62x11.2mm (H \* W \* D)

Weight 95q

Prestigio

Disclaimer

As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.

FN-4 Prestigio PAP3500





Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive1999/5/ES. Full version of the declaration of conformity is available on <a href="http://www.prestigio.com/compliance">http://www.prestigio.com/compliance</a>.

Prestigio PAP3500 EN - 5