


1. Packing List

- | | | |
|-----------------------------|----------------------|------------------|
| 1. Prestigio MultiPhone | 2. AC Adapter | 3. Earphone |
| 4. USB Cable | 5. Quick Start Guide | 6. Warranty Card |
| 7. Legal and Safety Notices | 8. Battery | |

2. Device Overview

- | | | |
|-----------|-----------------------------|--|
| 1 | Call Key | Enter Call log; Dial number |
| 2 | Vol + \ Vol - Button | Adjust the volume level |
| 3 | Power | Turn on/off the device;
Suspend/Activate the device |
| 4 | USB/Charge port | Micro USB cable/charge connection |
| 5 | Home | Back to the Home screen |
| 6 | Menu | Display menu options |
| 7 | Back | Back up to the previous page |
| 8 | Search | Enter search function |
| 9 | Earphone Jack | Earphone connection |
| 10 | Camera | Take photos |
| 11 | Flashlight | Help to take photos in the dark |
| 12 | Speaker | Listen to phone calls or music |



3. Uninstalling the back cover and battery

- Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.



- Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.

Notice: Your device must be powered off before exchanging or uninstalling the battery.

4. Installing the SIM cards and Micro SD card



a. Insert SIM cards

- The 2 card slots are both compatible with 2G GSM and 3G WCDMA card, but 2 cards must be different mode if you use 2 cards in your phone.
- Open the SIM card covers according to the picture one.
- Insert SIM card according to the picture two. Make sure the gold contact area on the card is facing downwards.
- Close and lock the SIM card cover.

b. Insert Micro SD card

- Open the Micro SD card cover according to the picture one.
- Then, insert Micro SD card according to the picture two.
- Finally, close and lock the Micro SD card cover.

5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3~4 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the time of full charging.



Notice: If you don't use your phone for a long time, it will gradually discharge. Please charge it first before your next use or charge the phone every 3 months even you don't use it.

6. Power on/Sleep Mode/Power off

- Press and hold the **Power Button** for a few seconds. It will automatically enter the **Home** screen after start-up screen.

- Press the **Power Button** once to enter sleep mode and press it again to awake the device.
- Press and hold the **Power Button**, and then tap on **Power off** to power off the device.

Technical Specifications

Processor	MT6575 @ 1 GHz
Memory	256MB RAM + 512MB ROM, Micro SD slot supports up to 32GB
OS	Android 4.0.3 (Gingerbread)
Display	4.3-inch IPS LCD, Capacitive multi-touch(5 Dots)
Resolution	480x800 pixels
Net Mode	WCDMA + GSM (UMTS:2100MHz; GSM:900/1800MHz)
Interfaces	USB 2.0, Micro SD (SDHC/SDXC compatible), USB Host
Communications	WiFi (802.11b/g/n), 3G
Battery	1500mAH Lithium-ion Polymer battery
Dimensions	127*68*11mm (H * W * D)
Weight	125g

Disclaimer

As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.



Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive 1999/5/ES. Full version of the declaration of conformity is available on <http://www.prestigio.com/compliance>.