

1. Packing List USB Cable

1. Prestigio MultiPhone

2. AC Adapter

3. Earphone

Quick Start Guide 8. Battery

6. Warranty Card

2. Device Overview

7. Legal and Safety Notices

Vol +\ Vol - Button Adjust the volume level 2 **Earphone Jack** Earphones connection.

3 **USB** port Micro USB cable connection.

4 Menu Display menu options.

5 Back Back to the previous page.

Back to the Home screen. Home

Turn on/off the device: Power


Suspend/Activate the device.

Camera Take photos.

Speaker Listen to phone calls or music.

3. Uninstalling the back cover and battery

 Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.



8







 Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.

4. Installing the SIM cards and Micro SD card



Insert SIM



Insert SD Card

a. Insert SIM cards

The slot on the right is card 2 slot for GSM card, the left is card 1 slot for 3G WCDMA card (compatible with 2G card).




• Please make sure the gold contact area on the SIM is facing downwards.

b. Insert Micro SD card

- To insert a Micro SD card, place the card connector towards the front side of the device and the printing side of
 the card towards the rear side of the device.
- To remove the micro SD card, pull the card out of the slot.

5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3.5 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the charging time.



6. Power on/Sleep Mode/Power off

- Press and hold the Power Button for a few seconds. It will automatically enter the Home screen after start-up screen.
- Press the Power Button once to enter sleep mode and press it again to awake the device.
- Press and hold the Power Button, and then tap on Power off/Standby to power off the device or to enter sleep
 mode.





Processor M16577 Cortex A9 Dual Core at 1 GHz	Processor	MT6577 Cortex A9 Dual Core at 1 GHz
---	-----------	-------------------------------------

Memory 1GB RAM + 4GB eMMC, Micro SD slot supports up to 32GB

os Android 4.0 (Ice Cream Sandwich) Display 4.5" TFT LCD, Capacitive multi-touch

Resolution 960*540 pixels Band WCDMA + GSM (UMTS:900/2100MHz; GSM:850/900/1800/1900MHz)

Interfaces

USB 2.0, Micro SD (micro SDHC compatible), USB Host Communications WiFi (802.11 b/a/n), 3G

Battery 1850 mAh Li-Poly battery Dimensions 135*78*9.5mm (L x W x H)

Weight 158a

As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.

Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given

Quick Start Guide Prestigio MultiPhone PAP4500 DUO

by the EU directive1999/5/ES. Full version of the declaration of conformity is available on http://www.prestigio.com/compliance.



Prestigio PAP4500 DUO EN - 5