COWON

DIGITAL AUDIO PLAYER

iAUDIO T2

BBE Mach3Bass MP3 DIGITAL AUDIO Ogg VORBIS Windows Media Mac OS LDB Lyric Data Base JetAudio

Thanks for purchasing COWON.

We always strive for your complete satisfaction of our product. This manual contains user guide, cautions and other useful information about your COWON player. Please read this manual thoroughly before using, to take full advantage of features in your COWON player.

Legal Notice
• COWON is a registered trademark of COWON SYSTEMS, INC.
• This product is intended for personal use only and may not be used for any commercial purpose without the written consent of COWN SYSTEMS, INC.
• Information in this document is copyrighted by COWON SYSTEMS, INC. and no part of this manual may be reproduced or distributed without the written permission of COWN SYSTEMS, INC.
• The software described in this document including JetShell and JetAudio are copyrighted by COWON SYSTEMS, INC.
• JetShell and JetAudio may only be used in accordance with the terms of license agreement and cannot be used for any other purposes.
• The media conversion feature in JetShell and jetAudio may only be used for personal use only. Use of this feature for any other purposes may be considered a violation of the international copyright law.
• COWON SYSTEMS, INC. complies with the laws and regulations related to records, videos and games. Complying with all other laws and regulations regarding consumer use of such media is the responsibility of the users.
• Information in this manual including contents of product features and specifications is subject to change without notice as updates may be made.
• This product has been produced under the license of BBE Sound, Inc. (USP4638258, 5510752 and 5736897). BBE and the BBE symbol are the registered trademarks of BBE Sound, Inc.

On-line registration and support
• Users are strongly encouraged to complete customer registration at http://www.iAUDIO.com. After filling out our customer registration form using the CD-Key and serial numbers, you can receive various benefits offered only to official members.
• 1:1 online support, news updates for new products or special events, and other services are available for our registered customers.
• Each CD-key is unique and will not be re-issued in case of loss.
• Further information regarding the product can be found on the web: http://www.iAUDIO.com
• Users will be able to find the latest information for other COWON products and download the latest updates for firmware and software.
• Frequently Asked Questions and Answers can be found on the website.

DIGITAL PRIDE

COWON

iAUDIO T2

- Do not use this product for any purpose other than described in this document
- Use caution opening the contents of the package to avoid injuries
- Do not use earphones while riding a bike, driving a car, walking, or exercising. It may disturb your concentration and lead to an accident.
- Avoid any exposure to extreme moisture. Damage from moisture constitutes user's negligence and will not be covered by manufacturer's warranty.
- Disassembling or modifying the device will void any warranty.
- Make sure the USB connection is made correctly to avoid any damage to the device or the PC. Avoid extreme bending or pressuring the connection.
- Avoid any excessive force or impact. If there is an unusual odor such as burning smell or excessive heating during use, stop using the device immediately and contact us through www.iAUDIO.com
- Do not use the player with wet hands as it may cause damage and malfunctions.
- Listening at high volume (over 85dB) for extended period of time is highly discouraged, as it may cause hearing problems.
- Use your player in well-lit places. Watching LCD screen in dark for extended period of time may increase eye strains and may cause sight problems.
- Avoid using the player at a location where static electricity is frequent
- Before any repair service, you should back up all data from the player. COWON SYSTEMS, INC. shall not be liable for any loss of data or files during the repair.
- Only use the AC adapter and USB cable provided by COWON SYSTEMS, INC.
- During lightning or thunderstorms, disconnect the player from the PC or AC adapter to avoid a risk of power surge or fire hazard.
- Store the player away from direct sunlight, excessive heat, fire and extreme cold environments. Excessive temperature can damage the exterior, interior circuits or the display.
- When using the player as a portable storage device, important data should be backed up as frequently possible. COWON SYSTEMS, INC. shall not be responsible for any unexpected data loss.
- Price of the player may fluctuate depending on the market condition, COWON SYSTEMS, INC. shall not compensate for any loss caused by price fluctuation.

1.1 iAUDIO T2 at a Glance

iAUDIO T2 is a unique multimedia player developed and manufactured by COWON SYSTEMS, Inc. It is a portable ultra-compact digital audio device that plays audio files such as MP3. iAUDIO T2 also offers FM radio listening/recording, and voice recording through a built-in microphone.

Highly portable, stylish and super-slim design with a neck strap
iAUDIO T2's ultra-slim size of 1.1 X 2.1 X 0.5 inches(earphone module excluded) provides portability and convenience.

12 hours of continuous playback with the embedded lithium polymer battery
The ultra power-saving circuit of iAUDIO T2 enables up to 12 hours of continuous playback with a fully charged battery. (Based on company test results.)

Multiple audio file format support
It supports various popular digital audio formats including MP3, OGG, WMA, WAV and FLAC (Free Lossless Audio Codec).

Powerful sound output of 46mW
When used with earphones of 16 ohm impedance, the maximum total sound output can reach up to 46mW for two channels (23mW +23mW) producing powerful and yet smooth sound qualities

Voice recording
Voice recording is available using the built-in microphone. This feature is particularly convenient for recording meetings or lectures.

Listening/recording of FM broadcasts
You can listen to FM radio broadcasts and record them at the same time. You can also save Preset channels for easy selection of your favorite FM radio stations.

Wide and vivid color OLED display
With 0.9 inch and 65,000 color OLED (Organic Light Emitting Diode), you can conveniently check the operational status of iAUDIO T2. It also supports multiple languages with display capability for over 40,000 different letters with embedded international fonts.

World's most powerful sound effects

iAUDIO T2 provides the most unique, powerful and high quality sound, which is recognized worldwide. You can take advantage of the following sound effects to suit your favorite music:

BBE: Sound effects that provide the clearest music.

Mach3Bass: A bass booster that enhances super low-end bass.

MP Enhance: Sound effects that compensate for missing sound segments in MP3s.

3D Surround: Three-dimensional surround sound effect.

Easily Upgradeable firmware

We may occasionally release firmware upgrades to incorporate improvements to the device and suggestions that users provide to us. You can easily upgrade your iAUDIO T2 with the firmware download feature.

Convenient features for learning language

iAUDIO T2 provides useful features such as section repeat, section search, bookmarks and playback speed controls. These convenient features are ideal for learning language

Timer function

T2 also offers convenience of internal timer function with alarm and timed recording.

Portable storage device

iAUDIO T2 is immediately recognized by a PC as a removable drive as soon as it is connected to a PC through a USB cable. No software installation is required to use it as a storage device.

JetAudio software

World famous integrated multimedia playback software, JetAudio Basic is included in your package.

1.2. Package Contents

Quick Guide,
Installation CD (with Serial Number)

Earphone module with
integrated neck strap,

iAUDIO T2

Simple USB Connector

USB Cable

AC Adapter (sold separately)

- Charge product with the USB connection jack and cable.

- The images of the package components are for your reference only and may differ from the actual item.

1.3. Features and Specifications

- MP3, OGG, WMA,, ASF, FLAC, WAV, FM Radio listening and recording, and voice recording
- High Capacity Internal Flash Memory (512MB/1GB/2GB), File Copy/Delete Capability
- High-Speed USB 2.0 Interface
- 0.9 inch OLED display with 96x96 resolution and 65K colors.
- Long Contiunous Playback Time: Up to 12hours (Based on company test result. Play time may be shortened if OLED is used often.)
- Multi-language support
- Enhanced Integrated file navigator
- Play/Pause during Playback, Record/Pause during Recording
- Next Track/Previous Track, Fast Forward/Fast Rewind, Infinite Loop
- Resume, Fade In, Auto Play feature support
- Search Speed, Skip Speed Setting
- Digital Volume Control :40 levels
- Various EQ and Sound Effects (JetEffect)
  - User adjustable 5-band EQ
  - Normal, Rock, Pop, Jazz, Classic, Vocal, User
  - BBE, Mach3Bass, MP Enhance, 3D Surround Support
- Clock, Alarm, Scheduled Recording, Sleep Timer, Auto Power-Off
- Auto display off feature to save battery power and screen burnout
- Easy firmware download and upgrade
- Title Display with ID3Tag or File Name
- Display Product Info (Firmware version, Total capacity, Total usage)
- USB Data Transfer Support for MAC OS (9.X, 10.X) and Linux (v2.2 and higher)

- Software
  - JetShell (File Transfer, MP3/WAV/WMA/AUDIO CD Playback)
  - JetAudio Basic (Integrated multimedia player software, music conversion feature)

Supported File Formats	MP3 : MPEG 1/2/2.5 Layer 3, ~320kbps, ~48khz, mono/stereo
	WMA : ~256kbps, ~48khz, mono/stereo
	OGG : ~q10, ~44.1khz, mono/stereo
	FLAC : compression level 0 ~ 8, ~44.1khz, mono/stereo
	WAV : ~48khz, 16bit, mono/stereo
Memory	512MB/1GB/2GB
USB Interface	High Speed USB 2.0
File Transfer Rate	Max 35Mbps (Upload Max 40Mbps)
Power Supply	Built-in Rechargeable Lithium Polymer battery(Max. 12 hours of continuous playback based on company test)
Charging Time	About 2 hours (either USB or Adapter)
Buttons	6 Buttons (REC, PLAY FF, VOL+, VOL-, MENU)
Display	0.9 inch 96x96 dots, 65,000 Color OLED
SNR	95dB (A-Weighted)
Output Frequency	20Hz~20KHz
Output	16 Ohm earphones : 23mW + 23mW
Dimension	iAUDIO T2: 1.14 X 2.07 X 0.53 inches (Width x Length x Thickness)
	Earphone Module: 0.69 X 0.66 X 0.63 inches (Width x Length x Thickness)
Weight	iAUDIO T2: 0.86 Oz. (including lithium polymer battery)
	Earphone Module: 0.23 oz.

1.4. Identifying the Parts

Top

Earphone Jack

Earphone module
with integrated neck strap

Left

MIC

MIC

- (VOL -)

MENU

+ (VOL +)

Front

COWON

Color OLED
Display

DIGITAL AUDIO PLAYER

Right

◀◀ (REW)

PLAY/STOP

▶▶ (FF)

To remove the earphone module

2

1

Bottom

USB Connection Jack

Reset

1.5. OLED Display

Section Repeat

Current Time

Boundary

Play Mode

Battery Status

AM
12:30 AB R SF

010/100

Current Track
/ Total Tracks

Song Title — iAUDIO Song

Progress Bar
Total Time

Play Time 0:01:30   0:04:30

The battery status icon indicates how much battery is left. The number of segments in the icon decreases as the battery discharges. For some batteries or rechargeable batteries, the number of segments in the battery icon may increase or decrease irregularly when the remaining charge is being measured. This is normal.

When the battery runs out, the battery icon starts to blink. If this happens, the player will automatically power off after about 30 minutes.

1.6. Charging iAUDIO T2

• If your player is being used for the first time or if it has not been charged for a long time, make sure player is charged fully before using it

• To charge iAUDIO T2, connect the player to a PC using a USB cable or connect to the AC provided adapter only.

(a) Using a PC connection

i. Connect the supplied USB cable to the USB jack of the player and directly to your computer. The connection to an external USB hub is not supported. The player must be directly connected to the PC via a USB cable.

ii. If the connection is made properly, the player will display an image showing charging status.

iii. To check the charging status, run 'Safely Remove Hardware' wizard on your PC. Then iAUDIO T2 will display charging status on its screen.

iv. Slow charging is recommended for notebooks and other devices that use battery power. See section 4.7 on changing the charging speed of iAUDIO

(b) Using an AC adapter (sold separately)

i. Connect the AC adapter to an electrical outlet and the USB jack of the player

ii. Once connected, the player will automatically turn on and start charging

iii. Once the player is fully charged, the charge complete screen will appear as shown.

- Genuine COWON AC adapter is sold separately and works for both 110V and 220V.
- For your safety, use only the adapter supplied by the manufacturer.

1.7. Windows 98 Driver Setup

When using Windows 98 or 98 SE, you need to install hardware driver for the PC to recognize the player.

•Windows 2000 and later versions automatically recognize the player.

■ **Installing the driver**

1. Connect the player to your PC using the supplied USB cable

2. "Add New Hardware Wizard" will appear as shown. Click "Next".

3. Click "Search for the best driver for your device (Recommended)", and then click "Next"

4. Click "Specify a location" and click "Browse" button.

5. Select "Win98" folder in the installation CD and then click "Next" button. Drivers are also available for download from www.iAUDIO.com.

6. Once the drivers are recognized, click "Next".

7. Continue to click "Next"

8. Click the "Finish" button to complete the driver installation. The newly added drive can be seen in Device Manager or Explorer.

1.8. Connecting to PC and Transferring Files

1. Connect the player to a PC using the supplied USB cable.

2. When connected, the screen will show the following screen.

3. The iAUDIO drive will appear as shown and can be accessed like a disk drive using Windows Explorer

4. Launch Windows explorer or JetShell Pro while iAUDIO T2 is connected to the computer to access the iAUDIO drive.
5. You can copy any files including MP 3files to and from "iAUDIO" Drive
6. To disconnect the player from the PC, first make sure that file transfers are complete and then, single-click on   icon on the windows tray.
7. Click on the following pop-up message when it appears

8. When "Safely Remove Hardware" message appears, and the OLED displays a battery you may disconnect the USB cable.

- The iAUDIO T2 can recognize up to 100 folders and 999 files.
- If iAUDIO drive does not appear in either My Computer or Windows Explorer, check the connection and settings, and then re-connect (Separate driver installation is required for Windows 98).
- If the USB cable is connected after running 'Safely Remove Hardware' wizard from the steps listed above, the player stays in the battery-charging mode. To access its memory, iAUDIO must be disconnected first and reconnected.
- If the device is connected through a USB HUB, the device won't be charged. The device must be connected directly to a USB port installed on a PC.
- In Windows 98 and 98 SE, the icon for "Safely Remove Hardware" may not appear. Instead, close the JetShell after file transfers have been completed, after which the player can be disconnected safely from the PC.
- If the following message appears, run Safely Remove Hardware after a few minutes.

1.9. Firmware Upgrade

Firmware is a program embedded in the hardware. By upgrading firmware, features of the product can be enhanced and any bugs be fixed. Performance and menus may change after a firmware upgrade. Some beta versions of firmware may contain program bugs that will be fixed in the later versions.
You can find the current firmware version of your player by selecting Settings-Information.
Upon upgrading the firmware, any data stored in the player may be lost, so it is recommended that data be backed up before upgrading the firmware.
The method of installing firmware may vary with each version. Be sure to check out further information regarding firmware on our website:www.iAUDIO.com.

2.1. Quick Start Guide

1. Connect the earphone/neckstrap module to the player
2. Press the ▶/‖ button to turn on the player,
3. After the splash screen and logo is displayed, the standby screen appears. (It may start playback if automatic play is selected in Settings.)
4. Press the ▶/‖ button to play or pause music
5. Pressing the ◀◀ ▶▶ buttons allows selection of previous and next tracks as well as fast forward and rewind the current track.
6. To turn off the player, press the ▶/‖ button and hold it until shutdown starts.

2.2. Basic Controls

iAUDIO T2 has 3 operation modes (Music, FM Radio, Record), in addition to File Navigation and Settings modes.
Pressing MENU button switches to File Navigation mode, Pressing MENU button twice switches to a screen for mode selection.
In the File Navigation mode, use − and + buttons to navigate between folders and files, and use ◀◀ ▶/‖ ▶▶ buttons for selecting folders and files. To change the values for items in Settings mode, press − or + buttons and selected values are applied immediately. To cancel a task in mode selection screen or in Settings mode and return to the standby screen, press MENU button.

	File Navigator Mode	Preset Search Mode	Mode Selection Screen	Settings Mode
	Move Up in folders	Cancel	Move to left	Escape the currently selected item
	Enter a folder Play a file	Open a Pop-Up Select a Pop-up	Select the mode	Select an item and apply highlighted value
	Open a folder		Move to the left	Select an Item or a folder
	Move the cursor up	Move the cursor up	Move to the left	Move cursor up Reduce the value
MENU	Switch to Mode Selection Screen Opens popup	Switch to Mode Selection Screen	Switch to the initial mode	Cancel the current value Return to initial mode
	Move the cursor down	Move the cursor down	Move to the right	Move cursor down Reduce the value

-If the player is in Music mode, File navigation mode appears. In FM radio mode, Frequency Preset mode appears.

3.1. Playing Audio Files

■ Playing Audio

1. After turning on the power, change the player mode to either Music
2. Press the [▶/॥] button to play music files.
3. Press the [▶/॥] button during playback to pause the media files
4. Press the [◄◄] [►►] buttons briefly to play previous or next tracks
5. During the playback, press the [◄◄] [►►] buttons to rewind or fast-forward the current track.

- If Auto play is enabled in the Settings menu, the player starts the playback upon power on.
- If Resume is enabled in the Settings menu, iAUDIO will resume automatically playback from the position where it was previously turned off.
- If a large number of files are stored in the player, it may take the player longer time to respond
- The player can recognize maximum number of 999 media files and 100 folders (This limit refers to playable music and does not include other file types)

■ Using Section Repeat

Press Long

AB Repeat

Section Repeat allows you to set a specific part of a track to play repeatedly.
1. During a music playback, press and hold the [MENU] button to initiate a pop-up screen.
2. At the start and end of the section to repeat, press [▶II] button once. An [AB] will appear on the screen and the selected section of music will repeat.
3. To cancel Section Repeat, touch the [▶II] button again.

- Minimum 1 second is required for section repeat to work.
- Section repeat function will be cancelled if another track is selected.

■ **Using Dynamic Playlist (DPL) and Bookmarks**
This function lets you edit a list of favorite music files. By using DPL user can access music files in various folders without navigating each folder. The bookmark function allows users to set where to start playing in each desired track.

▪ **Adding tracks to DPL**

Press Long

▪ **Removing tracks from DPL**

Press Long

▪ **Adding tracks to BookMark**

Press Long

▪ **Removing tracks from BookMark**

Press Long

1. To add a track while playback,to DPL or bookmarks, press and hold the [▶II] button to open a pop-up window. Then select the "Add DPL" or "Bookmark" from the pop-up menu.
2. To remove a track from DPL or Bookmark, select the file under DPL or Bookmark folder. Then press and hold the [MENU] button to open a pop-up window. And then select the "Remove" from the pop-up menu.
3. To remove all tracks from DPL or Bookmark," select DPL or Bookmark folder. Then press and hold the [MENU] button to open a pop-up window. And then select the "Remove All" from the pop-up menu.

- A track can be added to DPL in navigator, alternatively by opening a popup and selecting "Add to DPL"
- "Dynamic Play List" and "Bookmark" folder do not appear when connected to PC.
- When tracks are removed from the DPL or Bookmarks, only the link will be removed and the actual files are not deleted from the disk.
- If the actual file is deleted from the player, its entry is automatically removed from the DPL.
- Maximum 200 files can be added to DPL or Bookmark

3.2. Using FM Radio

■ Listening to FM Radio

1. Turn on the player and then select the FM Radio mode.
2. Press [◄◄] [►►] buttons briefly to change the tuning frequency at 0.1Mhz step
3. Press and hold [◄◄] [►►] buttons scan for the nearest FM radio station with good reception

- If you were listening to FM Radio before turning off the player, the player will automatically start with the FM Radio when turned on.
- Earphone wire works as an antenna for FM Radio signals and thus improves the quality of reception when straightened.

■ Setting and Using Preset Channels

Setting preset channels to favorite stations avoids manual scanning through all frequencies.

1. After the player is turned on, select the FM Radio mode.
2. Tune to the favorite station and press [MENU] button to change to a PRESET list.
3. Press +, - buttons to highlight the desired preset channel and then press and hold [►/■] button to open a pop-up window.
4. Select "Save Current Ch" to add the currently selected frequency to the PRESET list.
5. Listen to the preset channels by selecting "Listen Ch" or delete preset channels by selecting "Delete Ch"

6. In FM Radio tuning mode, pressing [►/■] button switches to PRESET scanning mode and "PRESET" appears on the screen.
7. Pressing [►/■] button in the PRESET scanning mode returns to FM tuning mode. The "PRESET" will disappear

-If there are no frequencies in Preset mode, the tuning frequency will not change.
-Up to 24 frequencies can be stored in Preset Channels.

■ Recording FM Radio

1. After the player is turned on, select the FM Radio mode.
2. Set the tuning frequency to the desired radio station.
3. Press and hold [MENU] button to start recording.
4. Press [MENU] button again to stop recording.

■ Scheduled Recording of FM Radio

1. Set the correct time on iAUDIO. Refer to section 4.6.
2. In the Settings / Timer menu, select the Wakeup Mode and set it to FM Recording
3. In the Settings / Timer menu, select the Wakeup Time and set it to desired time for recording.
4. The player will turn on automatically at the specified time and starts recording the FM Radio signal

- Recorded files are stored in "RECORD" folder
- During recording, battery consumption is higher than other playback operation.
- Sound quality and capacity of recordings may vary according to reception quality and recording settings. See the section 4.8 for further information

3.3. Recording Using Built-In Microphone

■ Recording with Built-in Microphone

Press Long

1. Turn on the power using the "PLAY" button and switch to the Record mode by pressing [MENU] button twice and then choosing Record icon.
2. Press and hold [▶❙❙] button to start recording with the built-in microphone
   During recording, press the [MENU] button to pause or resume the recording.
3. Press [▶❙❙] button to end recording.
4. To play recorded files, press [▶❙❙] button and listen on the earphones

- Recorded files are stored in "VOICE" folder if recorded via built-in microphone.
- To use JetEffect, Fast-forward and rewinding capabilities, the recorded audio files should be played in Music mode.
- If the player was in Record mode before turning the player off, the player will start with the Record mode when turned on again.
- Sound quality and capacity of recordings may vary according to reception quality and recording settings. See the section 4.8 for further information

4.1. Settings Menu List

Menu	Music
	FM Radio
	Voice Rec.
	Settings ▶
JetEffect	Equalizer
	BBE
	Mach3Bass
	MP Enhance
	3D Surround
	Pan
	Play Speed
	JetEffect Preset
Play Mode	Boundary
	Repeat
	Shuffle
Display	Language
	Title
	Play Time
	Title Scroll
	Scrollspeed
	Lyrics
	Auto Display Off
	Brightness
	Screen Saver
Timer	Time Setup
	Wakeup Mode
	Wakeup Time
	Sleep
	Auto Off

General	Skip length
	Scan speed
	Slient Scan
	Resume
	Auto play
	Fade in
	Charge
	Load Default
Recording	Voice bps
	FM bps
	Mic volume
FM Radio	Stereo
	Auto Scan
	Region
Information	

- Settings menu may change after a firmware upgrade.
- Display language in the Setting menu is described in section 4.5
- Settings menu operation is described in section 2.1- 2.2

4.2. Menu Screen

In this screen, you can select a Music, FM Radio, Recording or Settings mode.

3. JetEffect

1. Equalizer
· Use the preset settings or manually set 5 Band Equalizers(EQ). Preset EQ settings include Normal, Rock, Jazz, Classic, Pop, and Vocal. Each preset EQ can be edited to match user's preference.

2. BBE
· BBE is the sound effect that provides clear music

3. Mach3Bass
· Mach3Bass is the base booster that enhances super low-end bass.

4. MP Enhance
· MP Enhance: Sound effect that compensate for missing sound segments

5. 3D Surround
· 3D Surround provides three dimensional sound effects.

6. Pan
· Pan adjusts the left and right volume balance.

7. Play Speed
· Controls the speed of music playback
· It does not support for files with sampling rate less than 44kHz

8. JetEffect Preset
· To save current JetEffect settings or load the previous settings, press and hold button to open pop-up window and select SAVE or LOAD.

- Excessive JetEffect settings may strain sound and generate noise
- For further information regarding JetEffect, refer to BBE MP at our website: www.iAUDIO.com

4.4. Play Mode

1. Boundary
· This function sets the various ranges of files and folders.
· Boundary function is not available for recorded MP3 files.
   •All: Plays all tracks in all folders
   •Single: Plays only one track.
   •Folder: Plays files in the current folder
   •Subfolder: Plays files in the current folder including its subfolders.
· If tracks in DPL or Bookmark are played, boundary will automatically be set to the list. When a track in a general folder is played while tracks in DPL or Bookmark are being played, it automatically changes to normal boundary settings.

2. Repeat
· Within the range specified in the boundary, repeat playback can be set.

3. Shuffle
· Within the range specified in Boundary, random playback can be set.
· If enabled, files within the range are randomly played.

4.5. Display

1. Language
· Set the display language to use in iAUDIO T2.

2. Title
· Sets how the player displays file names on the screen.
· Choose ID3 tag to display tag information (artist, title) while playback.

3. Play Time
· Sets how it displays time information of current file.
· Play time shows elapsed playback time and Remaining shows the remaining playback time.

4. Title Scroll
· Sets how it scrolls titles displayed on the screen.
· If set to OFF, scrolling will be disabled and if set to One Way, text will scroll starting from the left side.

5. Scrollspeed
· Sets the scrolling speed for text displayed on the screen.
· Larger the number, faster the scrolling speed.

6. Lyrics
· iAUDIO can display lyrics of music files that contain lyric information.
· When enabled, lyrics of the music file being played is displayed on the screen.
· Music files without lyrics will not display lyrics even if this feature enabled.
· For more information on using lyrics, see LDB manager Guide at our website (www.iAUDIO.com).

7. Auto Display Off
· Sets how long the screen stays on before it turns off.
· If there is no operation for a specified period of time, the screen will automatically turn off.

8. Brightness
· Sets the screen brightness

9. Screen Saver
· By default Screen Saver is on
· More power is consumed when screen saver is running.

4.6. Timer

1. Time Setup
· Sets the current time
· Sets the correct time setting for alarm and scheduled recording.

2. Wakeup Mode
· Automatically turns on the player at the specified wakeup time.
· Music Alarm plays music and for FM Alarm settings, the last station to be listened to will run in Radio mode.
· For FM recording, it records the last radio frequency from the preset time during the specified time.

- FM Scheduled Recording uses more power than other features. Always make sure that the player is fully charged before using this feature.

3. Wakeup Time
· Sets the time to automatically turn the player on.
· Once sets the alarm for one time use, Daily sets the alarm for daily use.
· Duration is the period of time during which the alarm will stay on.

4. Sleep
· Automatically turns off the power after a specified time.
· After the preset time has passed, the player will automatically turn off even if a file is being played at the time.

5. Auto off
· When the player is stopped and no action is taken after a specified time has elapsed, this feature will automatically turn off the player.
· This function does not operate during playback.

4.7. General

1. Skip Length
· Sets the length of playback time skipped when the ⏮ ⏭ buttons are pressed shortly.

2. Scan Speed
· Sets the speed of Fast Forward/Rewind when the ⏮ ⏭ buttons are pressed and held.
· The faster the speed, the quicker scanning is possible.

3. Silent Scan
· Sets the sound during Fast Forward/Rewind operation. When selected, there is no sound during scanning.

4. Resume
· Saves the location of the music file played at the last power off.
· If enabled, when the player is turned on, it automatically plays from the last position where it was turned off.

5. Auto play
· Automatically plays files after the player is turned on.
· When enabled, the track last played will automatically start.
· When Resume is enabled, the player automatically plays from the last position.

6. Fade in
· Gradually increases volume when resuming playback after stop or pause.
· Sets how long it takes to increase the volume.

7. Charge
· Can choose charge mode On/Off.

8. Load Default
· Resets all the settings to default values except language setting.

4.8. Recording

1. Voice bps
· Sets the audio quality of the file recorded with the built-in microphone.
· Files recording through the microphone are set to Mono by default.
· The higher Kbps, the better the recording quality is, but file size also becomes larger.

2. FM bps
· Sets the quality of the file being recorded during FM Radio listening.
· Also sets the quality of scheduled FM recording file.
· The higher Kbps, the better the recording quality is, but file size also becomes larger.

3. Mic Volume

4.9. FM Radio

1. Stereo
· Select from Stereo and Mono when listening to FM Radio.
· Radio broadcasts that only support Mono will not support the Stereo feature.

2. Auto Scan
· Automatically scans for FM frequency channels and sets to preset channels.

3. Region
· Selects the country in which you are listening to FM radio

4.10. Information

· Version : The current version of Firmware

· Total Space : Total memory capacity

· Free Space : Currently available memory capacity

5.1. Resetting the Player to Factory Default Settings

iAUDIO T2's settings can be deleted and re-initialized to Factory default settings.

1. After the player is turned on, select the Music mode.
2. If a music file plays, pause at the playback screen and do as shown below.

Press Long   **Press Long**

3. When, initialized, the Language setting screen will appear when the player is turned on.

- If the player operates improperly, press the "RESET" button at the bottom of the player and then restart the player. If malfunction continues, please initialize the player to Factory Default setting.

5.2. Installation CD-ROM Contents

Inside iAUDIO Installation CD, you will find JetAudio, the world famous multimedia playback software, and JetShell, a manager program for iAUDIO. (Additional driver files for Windows 98 and 98 SE are also included)

What is JetShell?

JetShell is the iAUDIO manager program providing the following features:

- Downloading/Uploading files from/to iAUDIO.
- File management similar to Windows Explorer
- Playing MP3, MP2, WAV, WMA, ASF, Audio CD, and Playlist (m3u)
- Copying (ripping) MP3 files from Audio CD
- Converting between WAV/MP3/WMA
- Changing bitrate of MP3 files
- Convenient file transfer using Download List
- A wide selection of spectrums, equalizers, and sound effects
- Editing ID3 tags
- Downloading iAUDIO logo
- Formatting the flash memory

Running Environment for JetShell

- Pentium 200 Mhz or higher
- 32 MB or more memory
- 20 MB or more hard disk space
- 256 Color or higher display
- Windows 98/ME/2000/XP (NT is not supported)
- USB Port 1.1 or higher
- CD-ROM drive
- Sound Card, Speaker or Headphone

1. When you insert iAUDIO installation CD in the CD-ROM drive, the installation program starts automatically. It may not start automatically depending on the settings of Windows. In this case, run x:\setup.exe or x:\JetShell\setup.exe. (where x is the letter of your CD-ROM drive)

2. When the installation finishes, Start -> Program -> COWON -> iAUDIO T2 program group is created.

3. You are now ready to connect iAUDIO to PC (Don't run JetShell at this time).
Connect the USB ports of iAUDIO to your PC using the provided USB cable.
(We recommend to connect iAUDIO to the PC directly, not using USB hub)

4. As soon as the cabe is connected, the message "Found New Hardware" appears and the USB driver for iAUDIO is installed automatically. The driver installation message may not appear on the screen depending on the status of Windows. To make sure that the installation was completed normally, check for the device "iAUDIO" in My Computer as shown below, or "Control Panel -> System -> Hardware -> Device Manager".

5. Now you can transfer files by using JetShell or Window Explorer.

The Whole View

Play and MP3 Management Section

File Management Section

Flash Memory Management Section

File Management Window

Download List Management Section

When JetShell is running, it controls the iAUDIO. Make sure to exit JetShell before performing the following tasks:

• Installing iAUDIO's USB driver
• Formatting iAUDIO in Windows Explorer
• Upgrading iAUDIO's firmware

Player Section

Double click an MP3, MP2, WAV, WMA, ASF, Audio CD track, or Playlist (m3u) file in the "File Management Window", or drag and drop files on the "Player Window" shown above. You can also select multiple files and then press the Play button. On the black screen in the middle, various information of current file is displayed, and two types of spectrum screens appear.

You can start and stop playing the file with the buttons at the right, and adjust the volume with the + and - buttons. To skip instantly to a specific position of the track being played, click on the position bar.

File Management Section

The File Management Section of JetShell looks just like Windows Explorer. The left window shows folders, disks, and CD-ROM drives in a tree structure, and the right window shows the files in current folder.

Flash Memory Management Section

The bottom part of JetShell consists of "Flash Memory Management Window" and "Download List Window". When iAUDIO is working normally, the red lamp is turned on with the message "iAUDIO is working" as shown in the figure. The files in iAUDIO displayed in the middle window. The "Memory used" bar shown at the bottom right indicates the used memory size of the total flash memory of iAUDIO. If this bar is almost full, it means that there is almost no free space available in iAUDIO.

Button	Function	Explanation
	Up	Move to the upper folder.
	Properties	Display the properties of the selected file.
	Refresh	Refresh the contents of flash memory.
	Delete	Delete the selected file or folder.
	New folder	Create a new folder.
	Cut	Cut the selected file or folder.
	Copy	Copy the selected file or folder.
	Paste	Paste the cut or copied file.
	Transfer to Flash Memory	Transfer the selected files or folder from PC to iAUDIO.
	Transfer to PC	Transfer the selected files or folder from iAUDIO to PC.

JetShell displays visually cool spectrums. When you click on the spectrum display area, the screen changes as follows.

You can also enjoy various equalizers and sound effects.

Normal	Normal
Rock	Room Reverb
Pop	Big Room
Jazz	Hall Reverb
Classic	Stage Reverb
Vocal	Stadium Reverb
	Cathedral 1
	Cathedral 2
	Air Duct Reverb
	Metallic Reverb
	Simple Reverb
	Alien 1
	Alien 2
	Bass Boost
	Mega Bass Boost
	Simple Echo
	Distance Echo
	Long Echo
	Alpia Echo
	Double Echo
	Strange FB 1

Various Equalizers

Various Sound Effects

Downloading Music files to iAUDIO

If you want to download secure WMA files (WMA files from online music store) to iAUDIO, please refer to "Downloading secure WMA files to iAUDIO". JetShell does not support downloading secure WMA files. You can use Windows Explorer or other file management programs to download music files to iAUDIO.

1. Downloading music files to iAUDIO is very simple. Select files to download from the "File Management Window" and click down arrow.


2. Or you can also drag and drop the selected files from the "File Management Window" to the "Flash Memory Management Window".


3. The following window shows the file downloading process. Never disconnect the USB cable while downloading. Make sure that the LCD status is READY before disconnecting USB cable.

4. Another method is to put the files in the "Download List Window" first, and transfer them later.
This is useful when you wish to download files in different folders.

5. You can also download the files existing outside of JetShell by dragging and dropping them onto
the "Flash Memory Window".

## Converting Audio CD Tracks to MP3 Files and Downloading Them to iAUDIO

With JetShell, you can easily convert your Audio CD into MP3 files and download them to iAUDIO.

1. Before getting started, you must choose the quality of the MP3 files to create. Click [Setup] –[MP3
Encoder Option] to set the desired bitrate of the MP3 files. (The files compressed in a high bitrate
have a higher sound quality and a bigger file size.)

2. From the File Management section, select the CD-ROM drive in which the Audio CD is inserted. Select the audio tracks from the right window and click [• MP3] or [File] –[Convert CD to MP3] from the menu.

Convert CD to MP3
Convert WAV to MP3
Convert WMA to MP3

Convert MP3 to WAV

MP3 Bitrate Conversion

Format Device Memory...

Exit

3. Specify the path to save the MP3 files in. Choose a folder in iAUDIO to directly download MP3 files onto iAUDIO.

Save MP3 File(s)

Save in: Mp3

File name: Track   Save

Save as type: MP3 Files (*.mp3)   Cancel

## 3. Editing ID3 Tag

You can edit the ID3 tag of a MP3 file by selecting [Tools] – [Edit MP3 ID3 Tag] from the JetShell menu.

Find File or Folder...

Edit MP3 ID3 Tag...   Alt+3

ID3 Tag Editor

C:\WINDOWS\Desktop\Atomic Kitten - Feels So Good

Title Feels So Good
Artist Atomic Kitten
Album Feels So Good
Year 2002   Genre Pop
Comment http://canna.c4.to

Save   Cancel   Remove ID3

4. Downloading Logo File

You can download a logo file to change the logo screen that appears when iAUDIO powers on. Select [Download Logo File] from the menu. When the "Open" window appears, select the desired logo file and click Open. Then the logo file is downloaded and applied.

MP3 Encoder Option...

Download Logo File...

Open

Look in: Desktop

My Computer
My Documents
Online Services

File name: Open

Files of type: Logo File (*.lb)   Cancel

Q **I am still confused even after reading the manual.**
& Our website www.iAUDIO.com provides support for users of iAUDIO products with FAQ (Frequently Asked
A Questions) and beginner's guide for our products. Users are strongly encouraged to check out our website for
further information regarding product usages and software upgrades and patches.
For individual inquiries, please contact us on-line as we will try to help you best we can.

Q **I cannot turn on the player.**
& Charge the battery fully in case the battery charge has been drained. If the battery is weak it may take a few
A seconds to power on. If the player does not respond at all, first disconnect all USB and power cables, and
then press the RESET button located at the bottom of the player. RESET button simply powers off the player
and does not affect the player in any other way.

Q **Buttons do not respond.**
& Check if the power switch is set to HOLD
A

Q **The player is on but there is no sound.**
& Check if the volume is set to 0
A Check if the player has any music file stored in its disk. Damaged music files may not play or play improperly.
Check the connection of the earphones to the iAUDIO. Loose or blocked connection can cause inadequate
contact between earphone jack and the iAUDIO.

Q **Video won't play.**
& iAUDIO T2 does not support video
A

Q **FM Radio does not work.**
& iAUDIO does not have a separate antenna. Instead it uses earphone wire to receive FM Radio signals.
A Stretching the wires may enhance the reception quality. FM radio reception may be poor at locations where
FM radio transmissions are shielded. If FM radio does not work where reception should be possible, please
contact our service center (Note that reception quality of iAUDIO may differ from other FM radio receivers.)

Q **There is too much noise in my recordings.**
& iAUDIO T2 uses ultra-small embedded microphone, so it may be more susceptible to noise during record-
A ings.

Q **Characters on the display are corrupted.**
& Reset the language using Settings-Display-Language menu and set display format to File name using Set-
A tings-Display-Title menu.
If the problem continues, reset the player to its Factory Default setting. Some special fonts may not display
perfectly.

Q **Computer cannot recognize the player when connected.**
& When connecting to the PC with a USB cable, please turn the player on before connecting USB cable. If it is
A still not recognized by the PC, press RESET button next to the USB jack on the bottom of the player.
Connection to an external USB Hub may not be stable due to its low power. iAUDIO should be connected
directly to a PC's USB port.
iAUDIO may require additional driver installation for Windows 98 users. See section 1.7

Q **Player is not recognized by JetShell and "No iAUDIO found" message appears.**
& Check to see if the player is recognized in Windows Explorer when it is properly connected to PC. iAUDIO
A must be recognized in the Windows for it to work with JetShell.
Additional driver installation is required for Windows 98 and 98 SE users. See section 1.7.

Within JetShell, set Settings-Device to match your iAUDIO model.

Q **Memory capacity of the player is different or smaller than specified.**
& The memory capacity indicated by Windows Explorer may be different from that indicated by the memory
A manufacturer. Typically for a 1GB memory will display 954MB as its full capacity.
iAUDIO uses some area in the drive for system operation. Therefore, the actual available capacity is somewhat
reduced after excluding system area.

Q **iAUDIO does not play properly when memory is full.**
& For iAUDIO to function properly, it requires at least 5 MB of space for saving settings and other system files.
A